



## HID Corporation Edge™ Solo Part Numbers and Options

Edge™ Solo Product Description	Base Part	Rev. No.*	Color	Hardware Configuration	Configuration Option	iCLASS Elite Key <sup>1</sup>
<b>EdgePlus™ Solo ES400</b> Single door, IP-based stand-alone controller with built in web interface. Allows external connection to any Wiegand output (up to 128 bit ID) or most HID Clock & Data readers. Indoor use only. <b>Stand-alone integrated access control</b>	83000	A	K = Black	E = Externally-mounted reader	N/A	N/A
<b>EdgeReader™ Solo ESR40</b> Single door, IP-based stand-alone controller with built in web interface, with Integrated R40 iCLASS reader. Indoor use only <b>Stand-alone integrated access control</b>	83120	A	K = Black	I = Integrated reader	00 = Beep on, LED normally red, reader flashes green on tag read	0

For Technical Support, please call 800-237-7769 (Press option 4).  
For Sales support, please call 877-276-3346

\*Revision numbers and availability are subject to change without notice.

<sup>1</sup> 0 = Standard (Reads all iCLASS cards with unique keys diversified from HID master key)

**Example Part #:**

EdgePlus Solo ES400: 83000AKE

EdgeReader Solo ESR40: 83120AKI000